



65 feet of casing were removed from the bore hole. Cement was placed in bore hole via tremie pipe prior to removal of casing. 10 bags of quick gel bentonite were mixed with cement.