


Section 5, T4N, R37E, WM Section 32, T5N, R37E, WM Umatilla County

1 inch = 400 feet



Point of Diversion

Headgate with fish screen located in NE/4 of NW/4 of Section 5, about 162 feet S and 837 feet E from SW Corner of Section 32.

O Pumps

Two 200 horsepower turbine pumps located in building.
One pump operated at a time.

- - - Conveyance

Water conveyed from South Fork Walla Walla River to pump station via short reach of open ditch.

Water conveyed from pump station to rearing raceways via buried mainline (24-inch).

Water conveyed from rearing raceways to settling pond and outfall via buried mainline (24-inch).




Raceways

Used to hold/rear and spawn adult Spring Chinook salmon in NE/4 of NW/4 of Section 5.



Settling Pond

Used to treat water prior to discharge to river.



Measurement weir at outfall to South Fork Walla Walla River.



The purpose of this map is to identify the location of a water right. It is not intended to provide information regarding the location of property ownership boundary



FOUNTAINHEAD

1204 Alvarado Terrace Walla Walla, WA 99362 509.529.2646 phone



CLAIM OF BENEFICIAL USE App S-80879 Permit 53028

in the name of BONNEVILLE POWER ADMIN

Revised 01 DEC 2008